



Selecting the Proper Size stakWEL[®] Egress Window Well

STEP 1:

Measure and calculate dimension **A** as shown in the detail on the right based on the site's grade conditions and foundation height.

STEP 2:


Determine the required window well height by performing this simple calculation:

Required Window Well Height
=Dimension A + 7-1/2"

From the first column in the table below, select the closest height that will meet the site conditions.

STEP 3:

Once the height has been determined, read across and select the number of modules required for your site condition.



Note: stakWEL Window Wells meet building code requirements for emergency egress.

STANDARD SIZES AND MODEL NUMBERS

Window Well Height	stakWEL [®] Window Wells				
	Model #	Modules	Inside Width (inches)	Projection from foundation (inches)	Optional Dome Cover
		Number			
51-3/4"	stkwl-48	3	49-1/2"	40-1/4"	stkwl-48D
67-1/8"	stkwl-48	4	49-1/2"	40-1/4"	stkwl-48D
82-1/2"	stkwl-48	5	49-1/2"	40-1/4"	stkwl-48D
97-7/8"	stkwl-48	6	49-1/2"	40-1/4"	stkwl-48D

Note: stakWEL Window Wells cannot be used with 60" wide windows

stakWEL is designed for use on 36" and 48" windows only (See ScapeWEL model for 60" window installations).